

Operation precautions

All the safety and operating instructions should be read before the appliance is operated. The improper operation may cause irreparable damage to the appliance.

1. Installation condition

- 1.1 Put away from extreme hot places and humid places
- 1.2 Avoid direct sunlight
- 1.3 Be horizontally installed
- 1.4 Avoid violent vibrating ,lifts and place gently
- 1.5 Do not place other devices upon
- 1.6 Put in well ventilation places, not block the radiator fan in the back of the recorder

2. Installation and operation precautions

- 2.1 Please check the main power switch and voltage of power supply to avoid voltage mismatch. Attach the power cable to the unit and connect it to your local mains supply, then open the power
- 2.2 At the first use, assure the installation of hard disk, and the master-slave jumper wire should be set. MAXTOR hard disk is strongly recommend
- 2.3 Do not unplug the power connector before turn the power off correctly and switch the Power On & Off within short period
- 2.4 Unauthorized repair or parts substitutions may result in fire, electric shock or other hazards.
- 2.5 Do not attempt to service this equipment by yourself. Refer all servicing to qualified service personnel.

3. Open Cabinet And Check Inventory

Check the items supplied against the list below after open the case:

- 3.1 One power cord
- 3.2 One Ethernet cable (positive cable), one serial port cable
- 3.3 One package of installation kit
- 3.4 One user's manual
- 3.5 One CD for installation
- 3.6 Certification of the product
- 3.7 Product warranty card

Table Of Contents

Operation precautions	1
1. Installation condition	1
2. Installation and operation precautions	1
3. Open Cabinet and Check Inventory	1
Chapter 1: Product Features and Specifications	4
1. Technical Specifications	4
2. Product Features	5
Chapter 2: Installation	6
1. Hard disk installation	9
2. Front panel introduction	14
3. Remote controller	12
4. Back panel introduction	13
4.1 Serial port connection and extension	14
4.2 10-pin port connection	14
4.3 Alarm operation instructions	16
Chapter 3: Operating Instructions	21
1. Turn on / off the recorder	21
2. Recording operation	23
3. Alarm connection operation	24
4. Pan-tilt control operation	24
5. Network connection operation	24
Chapter 4: Front panel and remote controller operation	25
1. Operation menu introduction	25
1.1 Menu items' shifting and setting	25
1.2 Menu Overview	26
2. Menu Operation	30
2.1 Recording Operation	30
2.2. Playback operation	31

2.3. Playback fast forward.....	31
2.4. Playback slow forward.....	31
2.5. Control of Pan-tilt and Lens.....	32
2.6. Menu operation.....	32
Chapter 5: Operations over Network	38
1. Setting on the Client End.....	38
2. Login and Logout.....	38
3. Operation of the Right Click Menu(Video).....	42
4. Record Search and Playback.....	46
5. Config (System setting).....	49
6. Assistant	54
Chapter 6 Serial port operation	61
1. Super Terminal's software upgrading	61
2. Serial port upgrading operation.....	61
3. Control keyboard.....	62
4. Matrix connection	63
Chapter 7 Frequent Asked Questions.....	64

Chapter 1 Product Features And Specifications

1. Technical Specifications

Parameter	16 Channel		12 Channel	
	DH-DVR1604RW	DH-DVR1604	DH-DVR1204RW	DH-DVR1204
Operation system	Real-time operation system (RTOS)			
Processor	AMD ELANSC520/133 embedded microprocessor			
Video input	16 Channel (NTSC/PAL) BNC (1.0V _{p-p} , 75)		12 Channel (NTSC/PAL) BNC (1.0V _{p-p} , 75)	
Video output	1 Channel PAL/NTSC , BNC (1.0V _{p-p} , 75) video signal			
Audio input	16 Channel 200-3000mv10K (RCA)	4 Channel 200-3000mv10K (RCA)	12 Channel 200-3000mv10K (RCA)	4 Channel 200-3000mv10K (RCA)
Audio output	1 Channel 2000mv 1K (RCA)			
Video display	1,4,16 window display	1,4,16 window display	1,4,16 window display	1,4,16 window display
Video standard	NTSC (525 line, 60f/s) , PAL (625 line, 50f/s)			
System resource	16 channels real-time recording, one channel playback and network operation simultaneous		12 channels real-time recording, one channel playback and network operation simultaneous	
Image resolution	Real-time monitor 704 × 576, playback 352 × 288, VGA output 720 × 576			
Motion detection	Area setting: 396 detection areas on the screen; detection sense setting: 3 levels detection sense for each area			
Video compression	MPEG-4 CBR (Constant bit rate); MPEG-4 VBR (Variable bit rate)			
Audio compression	Audio : ADPCM			
Image compression rate	352 × 288 CIF format , 704 × 576 4CIF format			
Video recording speed	MPEG mode: PAL 1frame/10second-25f/s for each channel adjustable; NTSC 1frame/10second-30f/s for each channel adjustable			
Image quality	6 levels selectable			
Hard disk	4 IDE ports able to install 8 build-in HDDs, expand with external HDD case for another 12 HDDs			
HDD space used	Audio : ADPCM 28.8Mbyte/hour Video : 40-460Mbyte/hour			
Alarm input	16 channel voltage alarm input (+ 5 ~ + 15V D. C. Needed for the alarm input)			
Alarm output	6 channels output, (output in open/close contact)			
Alarm relay	24VDC 1A,220VAC 0.15A (relay output)			
MODEM connection	RS232			
Network connection	RJ45 10M/100M Ethernet connection			
Pan-tilt control	RS485			
Backup	CD-R, USB, HDD	PC HDD	CD-R, USB, HDD	PC HDD
Power	110VAC/220VAC			
Power consumption	60W		70W	
Working temperature	-10 - +55			
Working humidity	10 - 90			
Barometric pressure	86kpa - 106kpa			
Size	2U standard industrial case , 441 (W)x430 (L)x89mm (H)			
Weight	Approx 11KG(Without HDD weight)			
Installation method	Shelf installation; Desk installation			

2. Product Features

Real-time Monitor

- Video output port and VGA port, able to realize monitoring on the monitor or PC Type monitor
- Single window/4 windows/16 windows monitor
- Multi window /single window patrol sequentially on pre-determined intervals
- Display real time data stream and HDD occupying space per hour

Compression Method

- Multiple video compression modes: MPEG4 Constant bit rate、 MPEG4 variable bit rate
- 16-channel audio/video real-time compression, independent hardware compression for each channel, stable synchronization of sound and image

Storage

- 4 IDE port support up to 8 large capacity built-in HDD
- Alternate HDD working method, Hard disks can be put into idle mode if not accessed for a period of time. Greatly reduces the power consuming and heat emission, hard disks can be used for much longer time.
- Choose overwrite or stop modes with HDD full-covered situation

Back-up

- Support CD-RW drive to back up records onto CD through IDE port
- USB port support Multi-backup Device include removable HD, Flash disk
- Download the files on DVR to local PC through network

Play and record

- Support multiplex operation: Real time display/ record in all channels, one channel play-back, search for downloading, remote operations simultaneously while recordings are in progress
- Multiple recording mode: manual, schedule, alarm, motion detection, among which alarm recording and motion recording are with pre-recording function
- Playback: PIP or multi-channel function realize real-time monitoring during playback
Display the records on DVR through network

- Fast search and playback for schedule recording and alarm recording
- Multiple play-back modes: X2、 X4、 X12ast play, stop, 15F/S, 5F/S slow play and frame by frame playback
- Display the original event time when playback

Alarm relay

- 16 channels external alarm input, video lost alarm and motion detection alarm
- Multi channel alarm output relay switch realize quick alarm relay and on-spot light control
- Protection circuit for Alarm input and output assure the intactness of the main device

Pan-tilt Control

- Support the pan-tilt decoder using RS485 communication
- Able to integrate multiple decoding protocol so as to control various pan-tilt and speed dome

Communication connection port

- 10-pin special port to realize alarm input and pan-tilt-zoom control
- RS232 port support multiplex function: Connecting a Modem for the dial-up to the net; with keyboard for central control; connect to the computer serial port for system upgrading and debugging; or link to different matrix
- Standard Ethernet port for remote control via TCP/IP or HTTP

Network function

- Remote real-time monitor and operate
- Pan-tilt-zoom control
- Recording search and real-time playback (The image quality depends on the network condition), downloading through network
- System setting modification and system software upgrading
- Remote alarm process and system log review
- Embedded TCP/IP protocol and operation system supports Web server direct visit to realize all the functions above
- Administration mode: Support 3 levels user password protection, to prevent any unauthorized use of the product
- With 16 windows surveillance simultaneously at the customer end

Chapter 2 Installation

1.Hard disk installation

Since there is no built-in hard disc in the machine, please install HDD first refer to the below installation instructions. Up to eight 10G-infinite capacity hard discs can be installed internally. The installed HDD number can be decided according to the required image quality, recording time and HDD capacity.

Installation steps



Dismantle the top cover,
open the cabinet



Dismantle the HD bracket



Separate the up and down
part of the bracket



Install HD



Combine the two parts
of the bracket




Set the master-slave jumper wire
(refer to the clue on the back of the HD)



Fix the HD bracket



Connect HD data line to IDE port



Plug in HD power line



Close the cover and fix it

Note: It is not necessary to dismantle the HD bracket when less than 4 HDDs are installed
Recommend to use Maxtor HDD

CD-RW Installation



Dismantle the HD bracket



Remove the baffle of CD driver



Installed 4 HDDs



Fix the 5th HDD on the upside of the bracket



Fix two pieces of planks on each side of the CD-RW



Fix the CD-RW with bolts on the bracket

Note: Only can hold 5 HDDs if with a CD-RW installed
Support CD-RWs of current brands in the market.

2. Front panel introduction



- | | | | |
|--------------------------------------|--------------------------|--------------------------------|------------------------------|
| 1. Power switch and indication light | 2. Numeric Keypad | 3. Recording indicator light | 4. Plastic veil |
| 5. CD-RW | 6. Address | 7. Direction (left arrow) | 8. Remote receiver window |
| 9. ESC key (Cancel) | 10. Enter | 11. Direction (down arrow) | 12. Direction (up arrow) |
| 13. Direction (right arrow) | 14. Information | 15. Single window display | 16. Function assistant 2 |
| 17. Multi-window splitting | 18. Function assistant 1 | 19. Assistant indication light | 20. Standby indication light |
| 21. Jog Shuttle | 22. Windows shift key | 23. Record | 24. Cancel |
| 25. Play last section | 26. Slow play | 27. Play/pause | 28. Forward |
| 29. Play next section | 30. Enter | | |


Note: Outside Ring of the jog shuttle turning clockwise is equal to right direction arrow, turning counterclockwise is equal to left direction arrow; inner circle turning clockwise equal to down direction, otherwise equal to up direction.

Keys functions

Order	Key name	Logo	Function	Remark
1	Power switch and indication light	POWER	Power switch (Power off by pressing the key 4 seconds)	
			Indication light	
2	Numeric Keypad	1, 2, 3 etc.	Password input, window shift or number input	10 equals to 0 in number input
3	Recording light	Green on numbers	If the light is on green, it means under recording	
4	Plastic veil	Black plastic	Dust-proof	
5	CD-RW	CD - RW	Back-up records	
6	Address	ADD	Set address for remote control of the DVR	
7、 13	Left / right arrow	◀▶	Left / Right on screen Cursor control; shifting level 1 and level 2 menus; PTZ control.	
11、 12	Up down	▲▼	Up and Down on screen Cursor control; change setup; change number; PTZ control.	
8	Remote receiver		Used to receive the remote signal	
9、 24	Cancel	ESC	Escape or cancel	
			Go back to real time monitor from playback	
10	Enter	ENTER	Enter Cursor Selection	
			Enter main menu	
14	Information	INFO	Press to show the system information	
15	Single window display		Shift the display to single window	
16	Function assistant 1	Fn1	To display the PTZ and the camera control menu under full screen mode	
			To enable Cursor field selection with the arrow keys when set the MD area	
			To display the playback state bar during playback	
17	Multi-window splitting		During monitor shift to multi-window display	

18	Function assistant 2	Fn2	During playback realize PIP for the playback and real-time monitor with number key	
19	Function indicator light		Indicator light for the Function assistant	
20	Standby indication light		Light on when DVR stands by	
21	Jog Shuttle		Direction: Outer: left/right; Inner: up/down; Outer circle control fast forward/reverse when playback, Inner circle for frame by frame forward when playback	
22	Multi-window shifting	MULT	Multi-window shifting during real-time monitor; during playback, shift between playback and monitor window	
23	Record	REC	Start/stop recording, work with arrow keys or Num keys	
25	Play last section	⏮	Play the recording file before the current file	
26	Slow play	I▶	3 levels of slow play speed(15f/S、 5f/S、 frame by frame)	
27	Play/pause	▶ /	Play/pause	
			When in real time mode, press to enter record search menu	
28	Forward	▶▶	3 levels of forward speed (X2、 X4、 X8)	
29	Play next section	▶▶▶	Play the record next to the current file	
30	Enter	ENTER	Enter Cursor Selection	
			Enter the main menu	


3. Remote controller



- | | |
|---------------------------|-------------------------|
| (1) Address | (9) Jump forwards |
| (2) Multi-window shifting | (10) Play last sections |
| (3) Number | (11) Jump backwards |
| (4) Record | (12) Pause |
| (5) Function Assistant | (13) Play next sections |
| (6) Enter/Menu | (14) Slow play |
| (7) Cancel | (15) Play/Pause |
| (8) Direction | (16) Fast play |

✧ The operation of the remote controller is the same as the front panel.


4 . Back panel introduction



- | | | | |
|------------------------------------|---------------------------------------|---------------------------|---------------------|
| 1、 power switch | 2、 power plug | 3、 220V/110V shift switch | 4、 RS232 connection |
| 5、 VGA connection | 6、 Audio input | 7、 USB port | 8、 1394 connection |
| 9、 NET network connection (RJ45) | 10、 Audio output | 11、 Video output | |
| 12、 Alarm-RS485 connection | 13、 Video input | 14、 Video input | |
| 15、 Alarm output | 16、 Alarm output & control connection | 17、 Alarm input | |

Network connection note: When connect to the network card of the computer, please use reverse line; when connect to the exchanger or Modem, please use positive line.

4.1 Serial port RS232 connection and extension



- Note:
- The connection for program upgrading or debugging through serial port
 - The connection for dial-up login through MODEM
 - The connection for DVR control through keyboard

4.2 10-pin port connection


If you want to control pan-tilt, lens and process the relay of the alarming signals by the DVR, the 10-pin port can realize. The four 10-pin port can control various pan-tilt decoders, and the specific type of the decoder can be selected from the Control of the System setting in the menu. On plug the foot's serial number is marked.



- A: Alarm input: ALARM1~ALARM8
- B: Alarm input: ALARM9~ALARM16
- C: Alarm OUTput: ALARM1~ALARM5
- D:ALARM6 output and 12V controllable pressure AB line port

- Instruction of the controllable +12V :

Able to be the alarm output;
also able to be used to restore
the power of the smoke alarm sensor.





- Instruction of A、B line:

Used to connect the A and B line of the pan-tilt decoder

- Module sketch of the alarm input end




- Module sketch of the alarm output end



4.3 Alarm operation instructions:

1、 Alarm input:

- 16 channel alarm inputs, voltage input (Both Normal on / Normal close type)
- Please short connect between the alarm input end(COM) and the power (The power of the alarm sensor should be provided by outside power, the DVR afford +12V power, but if it provide power for more than two alarm sensors, it may affect the normal working of the DVR.).
- Please parallel connect the Ground of the DVR and alarm sensor
- Please connect the NC port of the alarm sensor to the DVR alarm input(ALARM)
- If you need to restore the touched-off alarm remotely, you have to supply the controllable 12 V power of the DVR to the alarm sensor, such as the smoke sensor.




2、 Alarm output:


- 6 channel alarm outputs (5 channel normally open , 1 channel NO/NC optional touch) .
- In order to avoid the overwork of the DVR, please refer to the related parameter of the relay, and see the attached form for the related relays' parameter.
- 1 channel controllable 12 V power output: Restore the touched-off alarm remotely such as the smoke sensor.

3、 Example:

Exam1: Infrared alarm sensor (Inside power and NC) and Alarm light output (please see PIC 1)



- 1、 Connect the sensor(NC) to the DVR alarm input(e.g.: connect to port 1)
- 2、 Connect the '+' of the alarm light to the '+' of the outside power, and '-' to the alarm output of the DVR(e.g.: connect to OUT2); Connect the cathode of the power to another port of OUT2
- 3、 Menu Setting


 ALARM	CH 0 1 TYPE NORMAL CLOSE No. 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 OUT REC SLOT1 08 : 00 - 24 : 00 ON SLOT2 00 : 00 - 24 : 00 OFF PRE-RECORDE ON DELAY 30SEC TIP OFF DEFAULT SAVE CANCEL	Alarm input from CH1 (Total 16 channel alarm input for choose) Normal close port Alarm output from CH2 (Be able to double choose according to the needs, it means 1 alarm input trigger several alarm output) Startup alarm recording (Be able to double choose according to the needs, two period a day for choose) Pre-record: Choose On means to save the monitoring image about 5SEC before alarming Delay: Lengthen the recording time after receiving alarm signals Tip: Choose ON means to pop up alarm notification in the screen Choose SAVE to save all the settings
--	---	--

4、 Purpose

During (8 :00 - 24 :00), when alarm input from Channel 1, the alarm output Channel2 was triggered and the alarm light on;
The screen display: Alarm input from CH1;The cameras CH1 and CH3 start recording simultaneity and save the monitoring image about 5SEC before alarm in;30 seconds after the alarm input be over ,the system stop alarm output and all the relative operation.


When alarm input out of (8 : 00 - 24 : 00),the alarm output is not triggered and do nothing

Exam2: Ele-lock (Without power inside and NO) and Buzzer output (please see PIC 2)



- 1、 Need afford '+12V' power outside;
Connect the '+' of the lock to the cathode of the power and '-' to the alarm input of the DVR (e.g.: connect to port 1);
Connect the Ground port of the power and the DVR.
- 2、 Connect the '+' of the Buzzer to the '+' of the outside power, and '-' to the alarm output of the DVR(e.g.: connect to OUT1);
Connect the cathode of the power to another port of OUT1

3、 Menu Setting

 <p>ALARM</p>	<p>CH 02</p> <p>TYPE NORMAL OPEN</p> <p>No. 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16</p> <p>OUT</p> <p>REC</p> <p>SLOT1 00 : 00 - 24 : 00 ON</p> <p>SLOT2 00 : 00 - 24 : 00 OFF</p> <p>PRE-RECORDE OFF</p> <p>DELAY 30SEC</p> <p>TIP OFF</p> <p>DEFAULT SAVE CANCEL</p>	<p>Alarm input from CH2 (Total 16 channel alarm input for choose)</p> <p>Normal open port</p> <p>Alarm output from CH1 (Be able to double choose according to the needs, it means 1 alarm input trigger several alarm output)</p> <p>Startup alarm recording (Be able to double choose according to the needs, two period a day for choose)</p> <p>Pre-record: Choose OFF means not to save the monitoring image before alarming</p> <p>Delay: Lengthen the recording time after receiving alarm signals</p> <p>Tip: Choose OFF means no alarm notification in the screen</p> <p>Choose SAVE to save all the settings</p>
--	---	--


4、 Purpose

When alarm input from Channel **2** anytime, the alarm output Channel **1** was triggered and the Buzzer sound; The cameras **CH3** start recording simultaneity; 30 seconds after the alarm input is over, the system stop alarm output and all the relative operation.

· Relays' parameter of the alarm output end

Model: G6H		
Material of the touch	Sliver	
Rating (resistance load)	Rated switch capacity	30VDC 1A, 125VAC 0.5A
	Maximum switch power	62.5VA 33W
	Maximum switch voltage	125VAC, 110VDC
	Maximum switch electric currenecy	1A
Insulation	between touches with same polarity	750VAC 1minute 50/60Hz
	between touches with different polarity	1000VAC 1minute 50/60Hz
	between touch and loop	1000VAC 1minute 50/60Hz
Surge voltage	between touches with same polarity	1500V (10 × 160us)
Length of open time	3ms max	
Length of close time	3ms max	
Longevity	Mechanical	100 × 10 ⁶ times (10Hz)
	Electric	200 × 10 ³ times (0.5Hz)
Temperature	-40~+70	

1.6 System menu structure



2. Recording operation

The default recording mode after the startup of DVR is 24 continuous recording for each channel. Users can program customized recording modes due to the necessity. Instructions for the different recording modes are as follows:

a) Schedule recording

·Enter the menu, and set the timing period for the recording. See details at [Menu>System setting>Schedule](#)

b) Manual recording

·Press “Rec” button on the remote controller or “●” on the front panel (Need input the administrator password)

·Check the status of each channel in the recording menu; “●” channels are in recording, while “○” means the channel is not in recording

·Select the channel to be recorded, please press the related number key(or use “▲ ▼” key / Jog shuttle choosing) make the channel “●” on the screen then press **Enter** to start the recording.

·Repeat above steps and make the channel “○” to stop the camera from recording.

·Press ESC to return and press ENTER to save the recording setting

c) Alarm recording

·Connect the alarm input according to the device connection and the instructions

·Made the related setting in the menu to start Alarm recording. See details at [Menu>Setting>Alarm setting](#)

d) Motion detection recording

· Record the channel only in need of motion detection. First confirm whether this channel is in schedule recording; if it is, please turn off schedule recording.

·Made the related setting in the menu to start Motion detection recording , See details at [Menu>Setting>Motion detection](#)

3.Alarm connection operation

- Connect the alarm input according to the device connection and the instructions
- Connect the related alarm output of DVR to associated alarm device (Example: light, beeper, etc.)
- Made the related setting in the menu , See details at **Menu>Setting>Alarm setting**

4.Pan-tilt-zoom control operation

- Confirm the proper connection of PTZ and Communication Protocol. Set the Camera address
- Confirm the proper connection between the PTA and the A、 B lines of DVR's RS485 port.
- Set the related items in the menu , See details at **Menu>System setting>Control**
- Select full screen call-up of associated PTZ Camera
- Press “Assistant” on the remote controller or “Fn1” on the front panel to shift the items on the screen
- Use direction key to move and control the selections on the screen

5.Network connection operation

- Confirm the correct network connection between DVR and computer
- Set the IP address, subnet mask and gateway of the computer and DVR separately (If there is no router in the network only the IP address is needed, if there is routers in the network, please set the related gateway and subnet mask)
- Open IE browser and input the IP address of the DVR you want to log in
- Network operation see details at **Chapter 5**

Chapter 4 Front panel and remote controller operation

1. Operation menu introduction












Flashing item is the current selectable one






1.1 Menu items' shifting and setting






Operation step	Button-pressing order	Instruction	Screen display
Enter main menu and level 1 submenu	1、 Confirm Enter	During real-time monitor, press to open the password prompt, input the correct password (default six 6 or six 8), then enter the menu.	
	2、 Direction(Jog shuttle)▲▼▶◀	Use arrows to select the main menu Icon Choice.	
	3、 Confirm Enter	Enter the selected level 1 submenu	
Enter level 2 submenu	4、 Direction(Jog shuttle)▲▼▶◀	Use arrows again to select level 2 submenu choice	
	5、 Confirm Enter	Press Enter to select level 2 submenu	
Set menu contents	1、 Direction(Jog shuttle) ▶	Select the option to be revised, flashing means being chosen	
	2、 Direction ▲▼	Press to revise the settings	
	3、 Confirm Enter	<u>Save</u> is flashing, choose to confirm whether you want to keep the revised setting.	
Exit the current menu	Direction(Jog shuttle) ◀	Return to the last option of the current menu	
	Cancel ESC	Exit to the last level menu	








◇ You can set the multiple channels and save the settings together before exiting the current menu





1. 2 Menu Overview

Main menu	Menu level 1	Menu level 2	Remarks
 SEARCH	RECORD  RECORD	CH 01 DATE 24-10-2002 TIME 02 : 20:20 PM PLAY START	Prepare for accurate playback according to the channel and time. See details at 2.6.1
	LIST  LIST	CH 01 TYPE ALARM DATE 24-10-2002 TIME 02 : 20:20 PM LIST START	List the results for choosing the wanted file to playback(R-General, A-Alarm, M-Motion detection).See details at 2.6.1
	ALARM  ALARM	CH 01 DATE 24-10-2002 TIME 02 : 20 SEARCH START	Not able to search motion detection records. See details at 2.6.1
 INFORMATION	FILE INFO  FILE INFO	START TIME 24-10-2002 09 : 20 END TIME 24-10-2002 20 : 20 FREE SPACE 00028318M	Display the the record starting/ending time and total free space of DVR's HDD. See details at 2.6.2
	HDD INFO  HDD STATE	HDD NUM 0 1 HDD CAPACITY 0 1 6 0 0 8 6M FREE SPACE 00028318M INDEX 1 2 3 4 5 6 7 8 MASTER - - - - - SLAVE  - - - - - CDR STATE NO USB STATE NO	Displayed the IDE ports' state, the total and free space for each HDD. “  ” means the current working HDD See details at 2.6.2
	VERSION  VERSION	BIOS VERSION 2.46 FILE VERSION 4.01 WEB VERSION 1.69 ISSUE DATE 08-16-2004	Display the information about operation system version, issue date and so on See details at 2.6.2
	BPS  BPS	CH.1 CH.2 CH.3 CH.4 0538Kb 0302 Kb 0267 Kb 0112 Kb 256M/H 132M/H 117 M/H 49M/H CH.5 CH.6 CH.7 CH.8 0663 Kb 0227 Kb 0050 Kb 0283 Kb 291M/H 99M/H 21M/H 124M/H CH9 CH.10 CH.11 CH.12 0663 Kb 0227 Kb 0050 Kb 0283 Kb 291M/H 99M/H 21M/H 124M/H CH13 CH.14 CH.15 CH.16 0663 Kb 0227 Kb 0050 Kb 0283 Kb 291M/H 99M/H 21M/H 124M/H	Display the current BPS and the estimate for HDD space occupy per hour See details at 2.6.2

Main menu	Menu level 1	Menu level 2	Remarks
SYSTEM SETTING 	GENERAL 	DATE 2003-07-13 FORMAT DD-MM-YY TIME 08:30:30 FORMAT AM/PM SAVE TIME HDD FULL OVERWRITE REC-LENGTH 60 MIN REMOTE ADDRESS 008 VIDEO MODE PAL SHUT PASSWORD OFF DEFAULT SAVE CANCEL	Set system time, recording parameter, the machine No., video format and so on See details at 2.6.3
	SCHEDULE 	CH 01 WEEK TIME1 TIME2 SUN 00:00 - 24:00 ON 00:00 - 24:00 OFF MON 00:00 - 24:00 ON 00:00 - 24:00 OFF TUE 00:00 - 24:00 ON 00:00 - 24:00 OFF WED 00:00 - 24:00 ON 00:00 - 24:00 OFF THU 00:00 - 24:00 ON 00:00 - 24:00 OFF FRI 00:00 - 24:00 ON 00:00 - 24:00 OFF SAT 00:00 - 24:00 ON 00:00 - 24:00 OFF ALL 00:00 - 00:00 ON 00:00 - 00:00 OFF DEFAULT SAVE CANCEL	Set schedule for Schedule recording , be able to set 2 different period everyday in a week separately. See details at 2.6.3
	IMAGE 	CH 01 NAME CHANNEL 01 QUALITY 06 FRAMERATE 25F/S BITRATE VBR VIDEO LOSS ALARM SHUT ALARM ALARM TIP NO TIP COVER SET OFF DEFAULT SAVE CANCEL	Set image quality, frame rate, coding format and so on See details at 2.6.3
	ALARM 	CH 01 TYPE NORMAL OPEN SERIAL 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 OUTPUT RECORD TIME1 00 : 00 - 24 : 00 ON TIME2 00 : 00 - 24 : 00 OFF PRE-RECORD OFF DELAY 30S TIP OFF DEFAULT SAVE CANCEL	Set Alarm output and the relay parameters See details at 2.6.3

Main menu	Menu level 1	Menu level 2	Remarks
SYSTEM SETTING 	PTZ CONTROL 	CH 1 PROTOCOL NONE ADDRESS 0 0 8 BAUDRATE 4 8 0 0 DATABIT 8 BIT STOPBIT 1 BIT VERIFY NONE DEFAULT SAVE CANCEL	Set PTZ protocol and the relative parameter See details at 2.6.3
	NETWORK 	HOSTNAME DVR1600 I P 192.168.000.111 SUBNETMASK 255.255.255.000 GATEWAY 192.168.000.001 WEB PORT 00080 TCPPOINT 37777 MONITOR TCP DEFAULT SAVE CANCEL	Set the network parameter See details at 2.6.3
	MOTION DETECTION 	CH 0 1 No 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 ALMOUT RECORD DELAY 30 SEC TIP OFF PRECORD ON LEVEL HIGH AREA SET TIME1 10:00AM—02:00PM OFF TIME2 10:00AM—02:00PM OFF DEFAULT SAVE CANCEL	See details at 2.6.3
	RS 232 	COMFUNC HYPETERM BAUDRATE 115200 DATA BIT 8 BIT STOP BIT 1 BIT VERIFYIFY NULL DEFAULT SAVE CANCEL	

ADMIN 	PASSWORD 	GUEST ***** CONFIRM ***** MANAGE ***** CONFIRM ***** SAVE CANCEL		If use manage password to log in, able to change password. See details at 2.6.4
	FILE MANAGE 	FILE DEL HDD SET MAINTENACE	DELETE ALL FILES ? OK CANCEL HDD 01 SETTING WORK-HDD No. 1 2 3 4 STATE w - - - OK CANCEL SUN OFF MON OFF ALL OFF SAVE CANCEL	Need Admin password
	OUT MODE 	FONT COLOR WHITE TIME-OSD ON TITLE WHITE CHAN-OSD ON POINT-CX 003 POINT-CY 003 MONHEIGHT 530 PLAYHEIGHT 530 VGA-MODE 1024*768*60 LOGO OFF ROTATE OFF INTERVAL 005S INDEX 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 OUTPUT1 OUTPUT2 DEFAULT SAVE CANCEL		May select the font color on the menu as you like. May set the original point on the real time monitor window , and the size of the real-time monitor and playback window. May select font color , and set channel rotating state
	ALARM IN 	ALARM IN 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 SAVE CANCEL		Enabled the alarm input manually
	ALARM OUT 	ALARM OUT 1 2 3 4 5 6 7 SAVE CANCEL		Give alarm output signal manually
	DEFAULT 	NETUSER DEFAULT	RESUME NETUSER? OK CANCEL SURE TO LOAD? OK CANCEL	Restore the original set Need Admin password.



 BACKUP	BACKUP RECORDS  BACKUP RECORDS	DEVICE HDD CH 1 SPEED FAST START TIME 2003-3-18 18 : 18 : 16 END TIME 2003-3-18 19 : 18 : 16 SEARCH START BACKUP START	Choose the backup device and select the wanted file to backup records See details at 2.6.5
	DEL BACKUP  DEL BACKUP	DEVICE HDD SURE TO DELETE ? OK CANCEL	
 LOGOUT	SURE TO LOGOUT? OK CANCEL		Exit the menu and need input the password on next logging in

2. Menu Operation

2.1 Recording Operation


Model	Button-pressing order	Instruction	Display
DH-DVR1604	1、 Record REC	Press to enter screen display. recording state non-recording state	Record:1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
	2、 Direction ▲▼ or the related number key	Press to shift the recording state on/off. means On.	Record:1 2 3 4 5 6 7 8
	3、 Direction ◀▶	Press to shift recording channels. The shadowed means On.	9 10 11 12 13 14 15 16
	4、 Record REC or Enter	Press to save the setting.	

2.2 Playback operation


Button-pressing order	Instruction	Display
1、Play/Pause	Press the button to enter screen display. (If the current state is logout, please enter password)	
2、Play/Pause	Press twice to begin the playback (on the screen shows channel, date, time). If it shows no record found, the operation will not take effect. After the completion of the playback, it shows “The End”.	

Record information display: during playback, press **Fn** to display or hide the playback state bar.

2.3 Playback fast forward

Button-pressing order	Instruction	Display
1、Fast forward ▶▶	During playback press this key to shift between 2 times speed, 4 times speed, 8 times speed.	
2、Play/Pause	During fast play press this key to shift between play and pause.	
3、Play next section, play last section	During playback state it takes effect. Press ◀▶ to view the next or last record of the same channel.	




2.4 Playback slow play

Button-pressing order	Instruction	Display
1、Slow forward I▶	During playback press to shift among X1/2、 X1/4、 X1/25 speed.	
2、Play/Pause	During slow play of the playback record press to shift between play and pause.	
3、Play next section, play last section	During playback state it takes effect. Press ◀▶ to view the next or last record of the same channel.	

◇ 1f/s speed slow forward is playing frame by frame.

2.5 Control of Pan-tilt and Lens

The current image must be shifted to the input image of the controlling camera

Button-pressing order	Instruction	Press Fn to display
1、 Refer to menu operation at 2.6.4	In Control setting , select the related Channel and Protocol , see the right picture. Set the conformed Baud rate and Address with the decoder. DATABIT with selection 4 to 8, STOPBIT with selection 1、1.5、 2 Press SAVE to save.	
2、 Assistant function Fn1	Under the state of single window monitor, press to enter the screen display. Press continuously to shift among PT CONTROL (DIRECTION), LENS CONTROL (ZOOM、 FOCUS、 IRIS), LIGHT CONTROL (OFF ON).	
3、 Direction ▲▼◀▶	Control the related pan-tilt, lens and light.	

2.6 Menu operation

Please refer to “ Menu option schedule ” ; Button operation refers to the above form.

All the below settings of the menu must be saved before taking effect.


2.6.1 Record search

The menu for record search is as the right picture :




Record

First set the channel, date and time you want to search, then select **START**, the playback begins.



List First set the channel, date and time you want to search, then select **SEARCH**, the screen shows the 8 recording files following the searching time. Use **▲▼** to select the file to be played. Press **ENTER** to begin the playback.

Note : the letters before the record are equal to following :
 R—Record ; M—Motion detection ; A—Alarm



Alarm First set the searching date, then select **START**, all the alarm records will be displayed. Press **▲▼** to select the record. Press **ENTER** to play the alarm record. Note : motion detection alarm can not be searched in this category, but can be searched in **RECORD** and **LIST**.




2.6.2 Information


Menu of Information see the right picture :




File Info Recording start time(the earliest recording time among all the HDDs) and recording end time. All the information is not changeable.



HDD Info Display HDD number, HDD capacity, remaining space, HDD index and the conditions of master drive and slave drive. If the HDD is in working, it will show as "W"



Version Bios version, File version, Web version and Issue date are showed. The information is not modifiable.



BPS Real time display bit rate of current channel (Kb/s) and space occupied. (MB/H)

CH.1	CH.2	CH.3	CH.4
0538Kb	0302Kb	0267Kb	0112Kb
256M/H	132M/H	117 M/H	49M/H
CH.5	CH.6	CH.7	CH.8
0663Kb	0227Kb	0050Kb	0283Kb
291M/H	99M/H	21M/H	124M/H
CH9	CH.10	CH.11	CH12
0663Kb	0227Kb	0050Kb	0283Kb
291M/H	99M/H	21M/H	124M/H
CH13	CH.14	CH.15	CH16
0663Kb	0227Kb	0050Kb	0283Kb
291M/H	99M/H	21M/H	124M/H

2.6.3 System setting

Menu of the system setting as the right picture:



General **DATE/TIME** are used to modify the current system date and time; after the modification reserve the change by selecting **SAVETIME**; in **HDDFULL** if selecting **OVERWRITE** system covers the previous recording files; **REC- LENGTH** can set the length of each recording file(15 mins, 30 mins, 60 mins or 120mins), **VIDEO MODE** :PAL and NTSC; **SHUT PASSWORD** :protect the system ,when ON,an advanced password is needed to shut off the system,when OFF,just press the power key for 4s to shut off the system.

GENERAL SETTING	
DATE	2003-07-13
FORMAT	DD-MM-YY
TIME	08:30:30
FORMAT	AM/PM SAVE TIME
HDDFULL	OVERWRITE
REC-LENGTH	60 MIN
REMOTE ADDRESS	008
VIDEO MODE	PAL
SHUT PASSWORD	OFF
DEFAULT	SAVE CANCEL

Note : System time cannot be changed freely; otherwise it would cause the malfunction of recording search.

Schedule Select the corresponding channel in **CH**. **WEEK** you can choose each day or setting the same with the 7days of one week by the key ALL. **TIME1** and **TIME2** express the timed recording period of the current channel. **TIME2** should be after the ending time of **TIME1**. The setting range is 00 : 00 - 00 : 00. **STATE** : ON means the time setting is on ; OFF means the time setting is OFF.

SCHEDULE	
CH	0 1
WEEK	TIME1 TIME2
SUN	00:00-24:00 ON 00:00-24:00 OFF
MON	00:00-24:00 ON 00:00-24:00 OFF
TUE	00:00-24:00 ON 00:00-24:00 OFF
WED	00:00-24:00 ON 00:00-24:00 OFF
THU	00:00-24:00 ON 00:00-24:00 OFF
FRI	00:00-24:00 ON 00:00-24:00 OFF
SAT	00:00-24:00 ON 00:00-24:00 OFF
ALL	00:00-24:00 ON 00:00-24:00 OFF
DEFAULT	SAVE CANCEL

Note : If you need record all day long, set **TIME1** as 00 : 00-00 : 00 , state is on; set **TIME2** as off.

Image In **CH** option select the related channel. **QUALITY** you can shift 6 levels circularly, in which the 6th level is the best quality. **Framerate** 1f/s-25f/s are selectable. **BITRATE** there are CBR(audio/video) and VBR(audio/video). **VIDEOLOST** :select port 1-6 for alarm output, prompting to select OFF means non-alarm output when video lost, meanwhile the prompt ON/OFF for the outside equip(port1-6) of alarm relay port means if pop-up alarm information or not. Select **SAVE** when finish the setting ,ESC for exit current setting. If you want to resume to the default, move the cursor to select DEFAULT and then select SAVE.

IMAGE SETTING	
CH	0 1
NAME	CHANNEL 01
QUALITY	0 6
FRAMERATE	25F/S
BITRATE	VBR
VIDEO LOSS ALARM SHUT ALARM	
ALARM	TIP NO TIP
COVER SET	OFF
DEFAULT	SAVE CANCEL

Alarm Select the relevant channel in **CH**(this recorder has 16-Ch alarm input). **TYPE** has normal on/normal close (electric output method) . **No.** If the number in RECORD is selected, recording would be started automatically when there is alarm input. If the alarm output port is chosen, it will trigger corresponding equipment when there is alarm input. CH7 is 12Vcontrollable output. **DELAY** means to lengthen the recording time after receiving alarm signals(1/6、1/2、1、3.....30min). When the outside alarm is canceled, the system will lengthen the recording time automatically before closing alarm and relay output. When Time 1、Time 2 are open, within the time of the setting the recording will be triggered by alarm signals. The beginning time should be earlier than the ending time; the setting in Time 2 should be later than the setting in Time 1. **PRE-RECORD**: Save the monitoring image for sometime before alarming. **TIP**: ON/OFF alarm prompt.

ALARM SETTING	
CH	0 1
TYPE	NORAML OPEN
No	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
OUTPUT	
RECORD	
TIME1	00 : 00 - 24 : 00 ON
TIME2	00 : 00 - 24 : 00 OFF
PRE-RECORD	OFF
DELAY	30S
TIP	OFF
DEFAULT	SAVE CANCEL

PTZ control Select the corresponding channel in **CH**, and choose the protocol of the brand name of corresponding pan-tilt decoder in **PROTOCOL**. **ADDRESS** is the address of the corresponding platform decoder **DATABIT**: selection4-8; **STOP BIT**: selection 1, 1.5, 2; **VERIFY**: odd, even and null

PTZ CONTROL	
CH	1
PROTOCOL	NONE
ADDRESS	008
BAUDRATE	4800
DATA BIT	8 BIT
STOP BIT	1 BIT
VERIFY	NULL
DEFAULT	SAVE CANCEL

Network **HOST NAME** display the name of the recorder. **IP** is set by using ▲▼ or input the exact numbers to change the IP address (IP address setting can only be realized in this term) ,and then set the correspond **SUBNETMASK** and **GATEWAY** **WEB PORT**, **TCP PORT** : in accordance with the user's network condition, the default port is 00080 and 37777. **MONITOR** can be selected by using ▲▼ (TCP/IP、 UDP) .Reserve the setting in **SAVE**, and restart the recorder.

NETWORK	
HOSTNAME	DVR1604
I P	192.168.000.111
SUBNETMASK	255.255.255.000
GATEWAY	192.168.000.001
WEB PORT	00080
TCP PORT	37777
MONITOR	TCP
DEFAULT	SAVE CANCEL

Note: UDP :The users with manage can monitor each channel freely, and other users can only view after them. Max 5 users can log in.

TCP Protocol : All users are able to monitor any channel. User shall select according to necessity. If the transmission is under Internet, TCP should be chosen. 2 users at maximum

Motion Detection Select the relevant channel in **CH**. **OUTPUT** “●” means startup alarm relay when detect the motion image; “○” means non alarm relay. Open or close the function in **DELAY**. Choose how long you want to continue the recording (1/6、 1/2、 1、 3.....30min) after motion detection is finished. **PRERECORD** save the motion detection. **SENS** has three levels: LOW, NORMAL, HIGH. **TIMING1** 、 **TIMING2** the way of setting the period of time is the same as the setting of ALARMSETTING.

MOTION DETECTION	
CH	0 1
No	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
ALMOUT	
RECORD	
DELAY	30 SEC TIPS OFF
PRECORD	ON
LEVEL	HIGH
AREA	SET
TIME1	10:00AM—02:00PM OFF
TIME2	10:00AM—02:00PM OFF
DEFAULT	SAVE CANCEL


AREA can be accessed by pressing **ENTER**. The setting area can be divided in 192 sections. Red section means the current cursor position, and green section is the motion detection area. The no color area is no motion detection area. Press **Fn** to locate the current section, then move the cursor to cover the MD needed area; press **Fn** again to choose the MD area.

RS232 **COMFUNC** select super terminal or Keyboard.
BAUDRATE select correspond baud rate. DATA BIT selection 1-8.
STOP BIT three selection 1、 1.5 and 2.
VERIFY odd and even


RS232	
COMFUNC	
HYPETERM	
BAUDRATE	115200
DATA BIT	8 BIT
STOP BIT	1 BIT
VERYIFY	NULL
DEFAULT	SAVE CANCEL

2.6.4 Admin

Menu of Admin setting is as the right picture:




Password Select **GUEST** and **MANAGE**. Press ▲▼ or the number key to change the password, then confirm the change by inputting the password again. Press **ESC** to go back to the sub menu. Only **MANAGE** level user can change the password.




Manage

FILE DEL Input advanced password, and enter **FILE DELETE**. If you are sure to clear the files on the HDD, click OK.



HDD SET Set working state of HDD. W means working HDD



Out mode **FONT COLOR**: default color, green, orange, blue and red, press ▲▼ to select.

POINT X, **POINT Y**: adjust the origination of the real-time monitoring window.


The numerical range of **POINT X** and **POINT Y**: 0—352 and 0—288.

MONITOR HEIGHT, **PLAYBACK HEIGHT**: Set the numerical range by using the direction key to zoom the window of real-time monitoring video and playback video. The range is 288-576.

OUTPUT1, it can rotate in a SPLIT 1/4/9/16 mode. Those channels marked with can be showed circularly after a certain interval.

OUTPUT2, it can rotate in a single window by window mode. Those channels marked with can be showed circularly after a certain interval.

Input the advanced password and press **ENTER** to confirm to select the default setting.



Alarm in Set Alarm input connection

ALARM IN							
1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
SAVE				CANCEL			

Alarm out Set Alarm output connection

ALARM OUT						
1	2	3	4	5	6	7
SAVE			CANCEL			

Default

Net user

Default

RESUME NETUSER?	
OK	CANCEL

SURE TO LOAD	
OK	CANCEL

2.6.5 Backup

Menu of Backup is as the right picture:



Backup records Move the cursor to select the backup device, channel number,

backup speed, starting data and time, ending date and time, and then select to start the backup, and system will display the backup processing. If the user does not connect the backup device right, system will give the hint: **No backup disk**; if the device is full, it will hint: **Disk is full**. During the backup, it will display the left time. For the backup device you can choose among HDD/USB/CDR. If the HDD is chosen as the device, the backup speed can be selected between **Fast** and **Normal**. If the backup speed is **Fast**, system will stop the current recording. When finishing backup, the system will get back to record automatically.

BACKUP RECORDS	
DEVICE	HDD
CH	1
SPEED	FAST
START TIME	2003-3-18 18:18:16
END TIME	2003-3-18 19:18:16
SEARCH	START
BACKUP	START

Delete backup Select the backup device (HDD/USB/CDR) you want to delete the records from first, and then confirm the deletion by selecting **OK**.

DELETE BACKUP	
DEVICE	HDD
SURE TO DELETE ?	
OK	CANCEL

2.6.6 Logout

Press OK to confirm logout.

SURE TO LOGOUT?	
OK	CANCEL


Chapter 5 Operation over Network

1. Setting on the client end

No software needs to be pre-installed. Please check the connection of the network, for example, ping the IP address of the DVR. If you can not ping through, please check the connection.

2. Login and logout

Please input the IP address of the DVR in the address column of the browser. Take DVR's IP address: 192.168.0.168 as an example: Input <http://192.168.0.168>. At the first time of visiting this DVR the system will pop up the dialogue box to ask whether you accept ActiveX or not, and please choose Yes, then the system will install the software automatically.



5-1

In this interface there are monitor video window, [login](#), [logout](#), [Video](#), [search](#), [config](#)(system setting), [Assistant](#)(assistant setting) and so on.

Login : Please click [login](#), and the following dialogue box will pop up.



5-2

Input username and password. There are three types of users: Administrator, User, and Guest. For the detailed introduction please refer to [User manage](#) in Assistant setting. The default username is admin password is admin. Please change the administrator password on time.

If after the input of the username and password, the following box pops up (5-3). The system is warning that some other user has used this name and logged in. Please use another name to log in.




5-3

If after the input of the username and password, the following box pops up (5-4). The system warns that the username just be inputted is unauthorized user or the password is wrong, and please tries again.



5-4


Log out: if the logged in user need to log out, please click logout button. After the popup of the following dialogue box, please choose Yes. See (5-5)



5-5

3.Operation of the right key menu (Video)

After you log in as Administrator, the buttons like login, logout, search, video, config, Assistant and so on are activated. Click the right key or click Video and the following interface will show :




5-6


If the DVR is 16 Channel, the real-time monitor will show 16 channel options; if 12 channel, it will show 12 channel options.

The right key/Video menu includes: Real time monitor, Decode quality, Video windows, Playback control bar, Pan-tilt control, Set volume, Net data flux, Full screen, Resize video and Video windows.

Real time monitor : Among the displayed channels, (5-7) you may select the channel you want to see, or press the numeric key to select the channels.




Decode Quality User can choose the decode quality according the needs, there are 4 levels quality for choose. (5-8)



Playback control bar : Please refer to **Records playback**.


Pan-tilt control : Control the direction moving of the pan-tilt and the zooming, aperture, focus of the lens. See 6 - 8. Press the related buttons to control. Note : Before the realization of the pan-tilt control you must set right the protocol of the pan-tilt on the DVR.



Set volume : It is for user to control the audio's volume. User can drag the bar to adjust or tick Mute to cancel the sound.




Net data flux : Display the statistics of the network transmission data flux. When no network data transmit the statistics shows zero.




Full screen : There are two way to realize full screen monitor: one is to double click the window directly; the other is to select Full screen among the right key menu. During multi-window state, choose one of the windows and make it full screen in the same ways.

Resize Video User can select different ratio to show different size of the video picture.




Video windows User can choose the display windows mode according the needs




4. Records Search and playback

Click on search, then pop up the dialogue box of records search




5-14

Input From and To recording time, channel number and searching type (Record or Alarm) , and the records during the searching time will show in the dialogue box (If only input the From time it show the records in 24 hours after the searching time). Click **Pageup** and **Pagedown** to display the next records. Double click the wanted record, and system will play the selected record, which can be played at full screen. At the same time you can also perform records download, and the record will be automatically saved in your PC's "C:\Download" folder.




During the playback, you can operate by the buttons in the playback bar like save record, stop save, capture picture, fast play, pause, and full screen. During the playback on the video screen it shows the channel number, time and data flux of the record.

Download : See (5-15), select the wanted record and click **Download**.




5-15

It supports the downloading of several records simultaneously. The default format of the downloaded records' names is as :file name +Channel N +date +time ,extension name is .mp4(Example: a-0120021205071028.mp4, 01 means channel 1, 20021205 means December 5th of 2002, 071028 means 7 o'clock 10 minutes 28 seconds).



5-16

Saved under Download file clip. Input the file name and choose **Save**. The screen shows the processing of the downloading until the completion. (User can use the Ctrl key to double choose several records and down load as a whole file as well)




5-17

5. Config(System setting)

Click **Config** button , and pop up the dialogue box. There are **General**, **Schedule**, **Alarm**, **Motion detection**, **Video parameter** six setting menus.

Note : The gray part of the menus you have to set on the local DVR.


General : Include the recording length setting. In Control Column select the channel number and its pan-tilt decoder's protocol, as well as the related address so as to realize the control of the lens and pan-tilt.



5-18


Schedule : (5-19) Able to select the different channel and date to perform the recording at the different period of time. There are two time periods for setting. The set time in **Time 1** and **Time 2** is independent with the set time in Motion detection. There is no week setting for Motion detection.

Motion detection time: User can set two time periods of the motion detection time and the state of the motion detection so as to activate the recording during the time period. Only when Motion detection is On, the set time period is taking effect. If the state of the two time period is both Off , the system view it as 24 hours motion detection Off.



5-19

Image : This menu can select the image quality and network transport protocols for each channel. Press SAVE aside the channel after finishing setting the property of the image. The user can continue setting the image property and press SAVE at the bottom of the dialog box to save all the settings.



5-20

Style: Among the options of the coding styles there are : VBR(variable baud rate), CBR(consistent baud rate), f/10s, f/5s, f/2s, 1f/s, 2f/s, 3f/s, 4f/s, 5f/s, 6f/s, 8f/s, 10f/s, 12f/s, 15f/s, 20f/s. Select one of the styles and save. For VBR and selectable frames there are 1, 2, 3, 4, 5, 6 level of image quality. Please choose due to the actual need.




5-21

Level 1 : data flux 128Kb/S ; Level 2: 256Kb/S ; Level 3: 384Kb/S ; Level 4 : 512Kb/S ; Level 5 : 768 Kb/S ; Level 6 : 1Mb/S. The different data flux demands on the related bandwidth and the transmission image quality is also different. Among them Level 6 demands on the widest band and has the best image quality.

Video lost alarm: when OFF, non-alarm for video lost; when ON, alarm. Frame rate selection: 1—25f/s.


Net transmission Protocol : there are TCP and Multicast two types. Multicast protocol: the user with control power can view the image at will and other users can only follow this user to view the image. 5 users are allowed to view at the same time. Be able to transmit 4 channels' image at the same time. TCP protocol: each user can view the image at will. According to the need, user can choose the different protocol. If it is through outer Ethernet you must choose TCP. 2 users are allowed to view at the same time.

Alarm :When there are alarm input signals, user can select the recording channel and the output port due the actual need. ALATM PORT: select ch1-16 or select all channels to set record channels. Tick off in channel boxes to select alarm channels and then select output port for alarm prompt. Click **SAVE PORT** to save current setting and click **SAVE** to save all settings.




5-22

Motion detection : When user set the time period outside the time setting in Schedule, motion detection will take effect. The blue area is the selectable motion detection area. User can move the dialogue box to choose the area and can also set the sensitivity of the area due to the need. Click **Full screen** or press right key on the area to display the motion detection area at full screen. After setting the area user can **Save channel** or **Clear** the area. If you want to set this channel fully as motion detection recording, you have to turn off the timing recording of this channel.



5-23


Video parameter Set the video parameter of the recording picture: image tinge, contrast, brightness and saturation. Press reset to get back default.



5-24

6. Assistant

Assistant : Click on Assistant setting, as following, there are **User manage**、**Record control**、**Apply for control right**、**Log information**、**System information**、**Alarm Prompt**、**Channel name**、**Upgrade BIOS** and so on.




5-25

User manage : display the user information of the DVR. The right buttons can let user save, add, modify, delete and cancel the information

Three levels users : Administrator fully set the system and modify the user information;

User can not set system parameter and modify other users' information;

Guest can not set system parameter and records search, can only modify personal information.



5-26

Add : Click Add to show the following dialogue box:



5-27


User can add user information in this dialogue box, select your power. There is only one administrator allowed.

Modify : Select this button to show the following. User modify the filled-in information.



5-28

Record control : Control the recording of each channel by hand




5-29

Apply for control power : Web client software can supply the login of multiple users. If you want to have the control power, you can click this option and confirm to have the control power (5-30). If user wants to have the control power, user has to apply and gain the authorization of the user with control power. If the logged-in users are all normal user, the first logged-in user gains the control power automatically. If Administrator logs in later, he or she can gain the control power by force. If only one user logs in or the logged-in user is the user with control power, the box is gray.




5-30

The following picture is other user is sending request to the user with control power.



5-31


Log information : The operations on the system are all recorded in log information (5-32). If choose **Save Log**, the Log will be saved automatically in the root directory of your PC's " C:\ as a text file (e.g.: C:\ 10.1.27.193-log.txt)



5-32


System information : Be able to check the basic information of the system. When sound is not needed, you can turn off the audio. Due to the bandwidth user can select the different Video transport mode, and after choose non real-time transmission, the mode is Extract I frame. Video type PAL or NTSC has to be selected right. If Auto recycles monitoring is on, system will shift among all the channels automatically and the time interval can be set.

Net data flux : During real-time monitor it shows the statistics of the network data flux.



5-33

Alarm Prompt When alarm occurs, user can select sound prompt .The sound file is System32>AlarmSound.wav. Click ALARM SELECT, user can select different prompt sound.



5-34

Channel name : Able to name each channel and the letters are no more than 12. The revised channel names will be displayed on the screen. The default setting of the channel name is Channel No.1 to Channel No.16




5-35

Upgrade BIOS : Able to upgrade the BIOS,WEB and BOOT program remotely. Open the related BIOS or Web file (example: DVR1604.BIN or Multi-webfile.bin) , and click on Send BIOS. After the upgrading, it will show the clue about the upgrading.



5-36

About : Version information



5-37

Chapter 6 Serial port operation

1 . Super Terminal's software upgrading

The system's operation can also be done through RS232 port. The specific operation is as following : First, copy "Terminal" and "system upgrade program" to the computer. Connect the computer with the DVR through RS232 port. Run "Terminal" program and create the connection between the computer and the DVR.

The setting information for the connection is:

- Baud rate— 115200bps
- Data bit— 8 digits
- Stop bit— 1 digit
- Check — no need
- Control on data flow— no

You can log in by username **admin** (default user with administrator power) for the serial port login.

Login steps :

Press any key to enter the login interface , which showing as following :

__Username : admin

Input the name; press the "enter" key. Then, input the password as following :

__Password : admin

.
If the username and password are correct, system enter serial port management menu interface. The detailed functions are the same as the menu setting.

2 . Serial port upgrading operation

After the setting of above operation, please follow the below operation :

Press any key to enter login interface as following :

__Username : admin

Enter username and press Enter. System hint to enter password as following :

__Password : admin


System gets into the **DEBUG>** state, and input BIOS and press Enter.

Click Communication in the menu——Send file, and open upgrading program file(DVR1604_PAL.BIN—16 Channel DVR BIOS program, please complete this operation within 20 seconds, otherwise overtime). System begins to upgrade automatically and after the upgrading system will restart automatically.

3. Control keyboard



The keyboard can be applicable to link multiple DVRs for uniform control and set the menu for single or multiple DVR, and also can realize pan-tilt control. The operation as following: First, select KEYBOARD CONTROL in MENU>SYSTEM SETTING>SERIALPORT CONTROL-SERIALPORT FUNC, and set the property (e.g. control protocol), and then connect the 25-pin RS232port conversion to the RS232 port on the DVR and at last set different remote IP addresses for the DVRs. When using the control keyboard, first input the remote IP of the DVR which the user wants to control, then the user can set the menu or operate the pan-tilt by ▲ ▼ ◀ ▶ and other buttons.



4 . Matrix connection

Before connecting the matrix to the DVR by RS232 port,the user should confirm with the provider that if the DVR has a matrix control protocol. After the connection, please set the matrix protocol to the DVR's serialport control,then the user can do operations such as control and switch through the panel or remote control.

Chapter 7 Frequent Asked Questions

1. What the sound of buzzer mean when normally start the machine

When the machine is started successfully, it would burst out a short ring.

When the HD could not be identified, it would burst out a long ring.

When communication with the controller panel is abnormal, it would burst out a voice of one long ring and two short in serial.

2. Uncontrollable of the recording time?

The recording time unit is one day. Besides schedule recording, there are other recording manners as dynamic detection recording, manure recording, external event triggering recording. Confirm each setting of them is correct.

3. The indicator light is flashing while recording ?

Check the external video inputting signal first. Such phenomena would happen when the inputting signal is not standard. If it is not the problem of the inputting signal, it must be caused by that the reading speed of HD is too slow. In this situation, the current HD should be changed.

4. How to dispose with the broken sectors of the hardware?

If the broken sector of HD is not too large, the machine would ignore and jump over it. Otherwise, system would eliminate this HD and output corresponding information.

5. What kind of external equipment could match the recorder?

It could work together with various matrix and decoders.

6. What is the standard for setting different picture quality in the recorder ?

It is not differed by resolution but by image quality.